

Pressure / Vacuum Meter

DigiMano 1000



Features:

- Accurate
- Pocket Size
- Dependable
- Luer Lock Fitting
- Large LCD Display
- Two Engineering Units
- Low Battery Indication
- Liquid and Gas Compatible
- 9 Volt Battery Operated
- Measures Pressure and Vacuum

Specifications:

Display: Large LCD 3 1/2 digits

Measures: Pressure or Vacuum.

Accuracy: 0.25% Full Scale \pm 1 Digit

Over Pressure: Three Times Pressure Range

Medium Compatibility: Non-Corrosive fluid and gas

Eng. Units: Combinations of units are available depending on the Model.

Models / Ranges: Several Models to Choose from ranges 2PSI to 20 PSI

Power: 9 Volt Alkaline Battery or Optional AC Adapter

Dimensions: 3 x 2 x 1.4 inches (7.6 x 5 x 3.6 cm)

Weight: 1 lbs (0.9kg) **Data Output:** 3.5mm Stereo Jack

The **Digimano 1000**, Pressure Vacuum Meter is a pocket size digital instrument designed to measure the pressure and vacuum of non-corrosive fluids and gases. The versatile instrument displays the reading on a large 3½ digit LCD Display

The **Digimano 1000**, Pressure Vacuum Meter has an accuracy of 0.25% full scale. Seven models with different engineering units and pressure ranges are available.

To provide superior performance, the **Digimano 1000**, Pressure Vacuum Meter incorporates one of the latest semiconductor sensors. It is powered by one 9V alkaline battery or an AC Adapter (Optional)

DigiMano 1000 Shown with Syringe Pump



Ordering Information:

Part #	Range / Units	Part Number	Range / Units
200 IN:	199.9 mmHg/199.9 inH2O	2000 IN:	1999 mmHg/199.9 inH2O
200 PS:	199.9 mmHg/19.99 PSI	2000 PS:	1999 mmHg/19.99 PSI
200 CmH20:	199.9 cmH20/19.99 PSI	2000 kPa:	199.9 kPa/199.9 inH2O
200 kPa:	199.9 kPa/199.9 cmH20	204	Syringe Pump



110 Toledo Street, Farmingdale, NY 11735, Phone: 631-531-0100, Fax: 631-531-0101

www.Netech.org 1-800-547-6557